

Element width (W)	Free width (w)
90mm French casement	$w = W1 + W2 - 579\text{mm}$
114mm French casement	$w = W1 + W2 - 603\text{mm}$
Element height (H)	Free height (h)
	$h = H - 100\text{mm}$